

WAVE



EU
2 pin



USA
2 pin



USA
3 pin



UK
3 pin



SWISS
3 pin



ITALY
3 pin



BRAZIL
3 pin



AUSTRALIA
2 pin



AUSTRALIA
3 pin



CHINA
2 and 3
pin



Matka-adapteri pikaopas

- **Adapteri ei muunna jännitettä tai taajuutta.** Tarkista ennen käyttöä, että laitteesi toimii kohdemaan sähköverkossa.
- **Käyttö:** Kytke sähkölaitteen pistoke adapteriin oikealla tavalla. Tarkista laitteesi pistokkeen oikea kytkentätapa tämän oppaan kääntöpuolelta. Kytke adapteri pistorasiaan.
- **Käytön jälkeen:** Irrota adapteri pistorasiasta.
- **Älä käytä laitetta, mikäli se on vahingoittunut.**
- **Älä altista laitetta kosteudelle. Vain sisäkäyttöön.**
- **Irrota adapteri pistorasiasta aina kun se ei ole käytössä.**
- **Älä liitä adapteria toiseen adapteriin.**

Travel Adaptor Quick Start Guide

- **The adaptor does not convert voltage or frequency.** Before use, make sure that your device is compatible with the local power network.
- **How to use:** Plug your device correctly to the adaptor. Check the correct way from the other side of this guide. Plug the adaptor into the power outlet.
- **After use:** Unplug the adaptor from the socket.
- **Do not use the device if it has been damaged.**
- **Do not expose to moisture. For indoor use only.**
- **Always disconnect the adaptor from the outlet when not in use.**
- **Do not connect the adaptor to another adaptor.**